

Carbon Fiber Fuse Box Cover**034 MOTOR  
SPORT**

034Motorsport's Carbon Fiber Engine Cover for the 8V Audi S3 & 8S Audi TTS is an overlay designed to tastefully complement the factory engine bay with a beautiful carbon fiber weave.

**Installation Spiciness Rating: MILD**

Installation of your 034Motorsport Carbon Fiber Engine Cover is a straightforward process that will take approximately 30 minutes to complete.

**Supplied Parts:**

- 034Motorsport Carbon Fiber Fuse Box Cover

**Tools Needed:**

- Isopropyl Alcohol
- Towel

About This Guide

This Install Guide documents the installation process on a 8V Audi S3. There may be minor differences depending on specific vehicle, market, options, etc.

Getting Started

Confirm you have received all the parts included with your purchase by reading the complete guide, if there are missing components, please contact:

[customerservice@034motorsport.com](mailto:customerservice@034motorsport.com)

## Install Steps

### Step 1

Open your hood to access the engine cover.



### Step 2

Using a towel and isopropyl alcohol, thoroughly clean the factory engine cover.



### Step 3

Peel the backing off of the 3M Adhesive Strips on the carbon fiber engine cover, exposing the adhesive.



### Step 4

Set the carbon fiber engine cover over the factory cover.





## Step 5

Once the carbon fiber engine cover is properly aligned, press down firmly to ensure the adhesive sticks.



## Step 6

You're done. Enjoy!

