



SWAY BAR END LINK, MOTORSPORT, FRONT, ADJUSTABLE MKIV VOLKSWAGEN

[Sway Bar End Link, Motorsport, Front, Adjustable MkIV Volkswagen](#)



These end links are manufactured from steel and feature Aurora spherical bearings, and are designed to replace the flimsy stock plastic and rubber units.

About This Guide

This Assembly Guide documents the process of the proper configuration prior to installation with the 034Motorsport parts that you have just purchased! Pictures and part numbers may vary, but the process remains the same.

Getting Started

- Confirm you have received all of the parts included with your purchase, if there are missing components, please contact customerservice@034motorsport.com

Collect the necessary tools required for installation by reading the complete Assembly Guide.





SWAY BAR END LINK, MOTORSPORT, FRONT, ADJUSTABLE MKIV VOLKSWAGEN

Supplied Parts:

- (2x) spherical bearings
- (2x) spherical heim joints with jam nuts
- (4x) dust boots
- (4x) spacers
- (4x) bolts
- (2x) nylon locking nuts
- (1x) packet of anti-seize

Tools Needed:

- (2x) capable hands

* We ship the dust boots uninstalled; once you have the alignment set, install the dust boots before final installation (optional).



Step A

Open hardware packages



Step B

Apply half packet of anti-seize to spherical heim joint



Step C

Run the jam nut down the shaft to disperse the anti-seize along the entire threaded portion

**Step D**

Thread the spherical heim joints into the spherical end links. Use the length of the stock component as a starting point for the length of the 034 adjustable end links; expand or compress as best fits your needs

