



Carbon Fiber Engine Cover, 8V Audi S3 & MkIII Audi TTS



**Supplied Parts:**

- 034Motorsport Carbon Fiber Engine Cover
- Pre-Applied 3M Adhesive Strips
- Scene Points

**Tools Needed:**

- Hands (2) (*Opposable thumbs are required!*)
- Isopropyl Alcohol
- Towel
- Patience

034Motorsport's Carbon Fiber Engine Cover for the 8V Audi S3 & 8S Audi TTS is designed to tastefully complement the factory engine bay with a beautiful carbon fiber weave that is perfectly matched to our X34 Carbon Fiber Audi S3/TTS Air Intake.

This genuine carbon fiber cover is an overlay for the plastic factory engine cover, retaining the factory Audi rings and TFSI logo for a true OEM+ appearance.

Installation of this upgrade is a simple process that takes approximately 30 minutes from start to finish.

**Step 1** – Using the process detailed in the Genuine Audi/Volkswagen Owner's Guide for your vehicle, open the hood to access the engine bay.

**Step 2** – Open the box for the 034Motorsport Carbon Fiber Engine Cover. Look at how pretty it is.

**Step 3** – Locate the factory Engine Cover. **Hint:** It's really hard to miss.



**Step 4** – Using a towel and isopropyl alcohol, thoroughly clean the factory Engine Cover.





**Step 5** – Peel the backing off of the 3M Adhesive Strips on the Carbon Fiber Engine Cover, exposing the adhesive.



**Step 6** – Carefully begin setting the Carbon Fiber Engine Cover over the factory plastic part.



**Step 7** – Once the Carbon Fiber Engine Cover is properly aligned, press down firmly to ensure the adhesive strips stick to the plastic cover beneath it.



**Step 8** – Marvel at your work!

