

[EA888.3 Billet Oil Filter Housing](#)**034 MOTORSPORT**

034Motorsport's Billet Oil Filter Housing is a direct replacement to the factory plastic piece that can be installed in minutes. The black anodized 6061-T6 billet will last the lifetime of the vehicle and will add another layer of finish to your engine bay.

## Installation Spiciness Rating: MILD



Installation of your 034Motorsport Rear Sway Bar is a straightforward process that will take approximately 30 minutes to complete.

**Supplied Parts:**

- (1x) 034 Billet oil filter housing

**Tools Needed:**

- 32mm Socket
- Torque Wrench

[About This Guide](#)

This Install Guide documents the installation process on a MK7 VW GTI. There may be minor differences depending on specific vehicle, market, options, etc.

[Getting Started](#)

Confirm you have received all the parts included with your purchase by reading the complete guide, if there are missing components, please contact:

[customerservice@034motorsport.com](mailto:customerservice@034motorsport.com)

**\*Note: Allow sufficient time for the vehicle to cool off before starting the installation.\***

### Install Steps


#### Step 1

Open your hood after the car has cooled off.



#### Step 2

Remove the engine cover by pulling upward.



#### Step 3

Using a 32mm socket, remove the factory oil filter housing.



#### Step 4

Remove the oil filter from the housing. If you have the older version housing, be careful not to break the adapter valve.




#### Step 4 cont.

Here are both versions of the factory oil filter housings. Regardless of which one you have, the steps are the same.



#### Step 5

To remove the filter support tube, gently push it side to side.



**Step 5 cont.****Step 6**

Install the filter support tube in the 034 billet oil filter housing by lining up the clips with the slots and push down. It will make a nice clicking sound when it connects.

**Step 7**

Slide the oil filter over the filter support tube.



#### Step 8

Coat the o-ring with a small amount of oil to prevent tearing.

#### Step 9

Thread the 034 billet oil filter housing into the factory location.




#### Step 10

Using a 32mm socket, tighten the housing until snug.



#### Step 11

Torque the housing to **25Nm-30Nm**.



#### Step 12

Put the engine cover back on and you are done.

